



HiPath 500
HiPath 2000
HiPath 3000
HiPath 5000

ISDN Telephones

Operating Instructions

SIEMENS

Global network of innovation

Before You Begin

These Operating Instructions describe which functions can be used on your HiPath 500, HiPath 2000 and HiPath 3000 / 5000 with commercially available ISDN telephones.

You may find that some functions you wish to use are not available on your telephone. This may be due to one of the following reasons:

- The function has not been configured for your telephone - please contact your service personnel.
- Your communications platform does not support this function - please contact your service personnel.

For the basic operating functions of your telephone please refer to the relevant operating instructions.

CE (customer equipment) does not continue to support emergency dialing after loss of mains power, if battery back up and power fail switchover to emergency analogue phones is not available.

The information provided in this document contains merely general descriptions or characteristics of performance which in case of actual use do not always apply as described or which may change as a result of further development of the products.

An obligation to provide the respective characteristics shall only exist if expressly agreed in the terms of contract.

The trademarks used are owned by Siemens AG or their respective owners.

Contents

Before You Begin.....2

Basic operating instructions.....6

How to Use these Operating Instructions.....	6
Accessing Functions.....	7
... With Codes.....	7

Making and Answering Calls.....8

Answering a Call.....	8
Using Call Waiting.....	9
Accepting a Waiting Call (Camp-On).....	9
Preventing and Allowing Call Waiting (Automatic Camp-On).....	10
Turning the Call Waiting Tone On and Off.....	10
Accepting a Specific Call for Your Colleague.....	10
Using Mailboxes.....	11
Using Timed Reminders.....	11
Turning Do Not Disturb On and Off.....	11
Trace Call: Identifying Anonymous Callers.....	12
Answering Calls from the Entrance Telephone and Opening the Door.....	12

Making Calls.....14

Dialing Numbers.....	14
Caller ID Suppression.....	14
Talking to Your Colleague With a Speaker Call.....	14
Talking to Your Colleague with Discreet Calling (Not for HiPath 500).....	15
Activating Tone Dialing/DTMF Suffix-Dialing.....	15
Automatic Connection Setup (Hotline).....	16
Reserve Trunk.....	16
Assign Station Number.....	17
Associated Dialing/Dialing Aid.....	17

Calling Multiple Parties Simultaneously.....18

Calling a Second Party	
(Consultation Hold; not for all ISDN Telephones).....	18
Switching to the Party on Hold	
(Toggle; not for all ISDN Telephones).....	18
Conducting a Conference (not for all ISDN Telephones).....	19
Adding Up to Five Parties to the Conference (Initiator Only).....	19
Leaving a Conference.....	19
Ending a Conference (Initiator Only).....	19

Transferring a Call (not for all ISDN Telephones) 20
 ...After a Speaker Call (Announcement) in a Group 20
Parking a Call (not for all ISDN Telephones) 21
 Retrieving a Parked Call 21
Picking up (Retrieving) a Held Call 21

Making Calls to Stored Destinations 22

Using Station and System Speed-Dial Numbers 22

Checking and Assigning Call Charges 23

Dialing with Call Charge Assignment 23

If You Cannot Reach a Destination... 24

Call Waiting (Camp-On) 24

Telephone Settings 25

Locking the Telephone to Prevent Unauthorized Use 25
Saving Your PIN 26

Saving Station Numbers and Appointments 27

Storing Station Speed-Dial Numbers 27
Saving Appointments 27

Call Forwarding 28

Using Variable Call Forwarding 28
Using Night Answer 29

Using Other Functions 30

Sending a Message 30
 Deleting Sent Messages 30
 Answering Messages 30
Using Another Telephone Like Your Own 31
Resetting Services and Functions
(System-Wide Cancellation for a Telephone) 31
Recording Calls 32
Monitoring a Room 33
Activating Functions for Another Telephone 34
Locking Another Telephone to Prevent Unauthorized Use 35
Using System Functions from the Outside
(DISA: Direct Inward System Access) 35

Controlling Connected Computers or Other Programs and Telephone Data Service (Not for HiPath 500)	37
Controlling Relays (Not for HiPath 500/HiPath 2000)	38
Paging (Not for HiPath 500)	39

Team and Executive/Secretary Functions With Assigned Trunk Lines 40

Forwarding Calls on Lines	40
Transferring Calls Directly to the Executive (Only in an Executive/Secretary Group)	41

Using Other Team Functions 42

Turning Group Call On and Off	42
Accepting a Call for Another Member of Your Team	43
Activating and Deactivating a Ringing Group	43

Special Functions in the LAN (Not for HiPath 500) 44

Leaving a Hunt Group/Group Call	44
Transferring Call Forwarding	45
Using Night Answer	46
Activating and Deactivating a Ringing Group	47
Controlling Relays (Not for HiPath 2000)	48
Opening the Door	49

Documentation 50

Index 51

Overview of Functions/Codes (Alphabetical) 54

Step by Step

Basic operating instructions

How to Use these Operating Instructions

You will find a graphic representation of the steps in logical sequence in the left column. Below is an explanation of the symbols:



.Lift the handset (off-hook)



Replace the handset (on-hook).



Conduct a call.



Enter a telephone number or code.



Enter the code.



Consultation hold key (if available).



You hear a tone.

A long tone (positive confirmation tone) confirms that you have successfully activated a function or procedure. A short tone (negative confirmation tone) indicates that the function or procedure was rejected.

Step by Step

Accessing Functions

... With Codes

You can activate the functions of your system **by entering codes** such as:

7 5 9 7

DND (do not disturb) on.

7 6 9 7

DND (do not disturb) off.

All codes to activate or enable functions are always introduced with the digits **7 5**, and all codes to deactivate, disable or delete functions always begin with the digits **7 6**.

The codes themselves may contain up to three digits.

An alphabetically ordered overview of all functions and their corresponding codes can be found in the **Appendix** ("Overview of Functions/Codes (Alphabetical)" → Page 54 = Quick-Reference Operating Instructions).

Step by Step

Making and Answering Calls

Special default ring signaling is set for your telephone:

- When you receive an internal call, your telephone rings once every four seconds (single-tone sequence).
- When you receive an external call, your telephone rings twice in rapid succession every four seconds (dual-tone sequence).
- When you receive a call from the entrance telephone, your telephone rings three times in rapid succession every four seconds (triple-tone sequence).
- If a call is waiting, you hear a short tone (beep) every six seconds.



Your service personnel can adjust the ring cadence for external and internal calls for you. In other words, different ring cadences can be set for different internal callers.

Answering a Call

The telephone rings.



Lift the handset.



If your telephone has a display and a CLIP function (Calling Line Identification Presentation), the calling line or name of the caller (CNIP) will be shown in the display, even before the connection is picked up. This is assuming that calling line identifier presentation is activated, not deliberately suppressed, and that the CLIP function has been configured by your service personnel.

Ending the call:



Replace the handset.

Step by Step

Using Call Waiting

Callers can still reach you while you are engaged in another call. A signal alerts you to the waiting call.

You can either ignore or accept the waiting call. When you accept the waiting call, you can either end the first call or place it on hold and resume the call later on.

You can also bar call waiting or the call waiting tone
→ Page 10.

Accepting a Waiting Call (Camp-On)

Precondition: You are engaged in a phone call and hear a tone (every six seconds).

Ending the first call and answering the waiting call:



Replace the handset. Your telephone rings.



Answer the second call. Lift the handset.

Placing the first call on hold and answering the second call (not for all ISDN telephones)

R **7** **5** **5** **5**

Enter the code.

You are connected to the call waiting party immediately. The first party is placed on hold.

Ending the second call and resuming the first one:

R

Press the key.

7 **5** **0**

Enter the code or wait two seconds.

or

(depending on the configuration)

R

Press the key twice.

Step by Step

Preventing and Allowing Call Waiting (Automatic Camp-On)

If this function has been configured (ask the service personnel), you prevent or allow a second call → Page 9 from being signaled by automatic camp-on during an ongoing call.



Lift the handset.

Enter the code for "off (prevent)".

Enter the code for "on (allow)".

Turning the Call Waiting Tone On and Off

You can suppress the call waiting tone (approx. every six seconds) for external calls. A one-time special dial tone then alerts you to the waiting call.



Lift the handset.

Enter code for "tone off" or "tone on".

Accepting a Specific Call for Your Colleague

You hear another telephone ring.



Lift the handset.

Enter the code.

Enter the number of the telephone that is ringing.

 Accepting calls in a team → Page 43.

Step by Step

Using Mailboxes

If there are messages waiting for you, you will hear a special dial tone (continuous buzzing) when you lift the handset.



7 6 6 8 3

Lift the handset.

Enter the code.

This connects you to the sender of the message or the mailbox system.

Using Timed Reminders

Precondition: You must have saved a timed reminder → Page 27. The current time is the time stored.



Your telephone rings.

Lift the handset and replace it again.



If you fail to answer the timed reminder, it repeats five times and is then erased.

Turning Do Not Disturb On and Off

You can activate the do not disturb function if you do not want to receive any calls. When do not disturb is activated, internal callers hear a busy signal and external callers are rerouted to a telephone assigned for this purpose (ask the service personnel).



7 5 9 7 or 7 6 9 7

Lift the handset.

Enter the code for "on" or "off".



When you lift the handset, a special dial tone (continuous buzzing) reminds you that "do not disturb" is active.

Authorized internal callers can automatically override the do not disturb function after five seconds.

Step by Step

Trace Call: Identifying Anonymous Callers

You can have the carrier identify malicious external callers. You can save the caller's station number during the call or for 30 seconds after the call ends. However, it is essential that you do not replace your handset during this time.

You are engaged in an external call.



Enter the code.



After you have finished tracing the call, the data is stored on the carrier's system. Now contact the service personnel.

Answering Calls from the Entrance Telephone and Opening the Door

If an entrance telephone has been programmed, you can use your telephone to speak to someone at the entrance telephone and to activate a door opener.

If you are authorized to activate a **door opener** (contact the service personnel), visitors can open the door themselves by entering a 5-digit code (using a DTMF transmitter or installed keypad).

Speaking to visitors via the entrance telephone:

Precondition: Your telephone rings.



Lift the handset within thirty seconds. You are connected to the entrance telephone immediately.

or



Lift the handset after more than thirty seconds.



Dial the entrance telephone number.

Opening the door from your telephone during a call from the entrance telephone:



Enter the code.



Dial the entrance telephone number.

Step by Step



Special features must be taken into consideration if your telephone operates with HiPath 5000 (system networking via PC network) → Page 49!

Opening the door with a code (at the door):



After ringing the bell, enter the five-digit code (using the keypad or a DTMF transmitter). Depending on how the door opener has been programmed, a doorbell call signal may or may not be forwarded.

Activating the door opener:



Lift the handset.



Enter the code.



Dial the entrance telephone number.



Enter the five-digit code. Default code = "00000" (contact the service personnel).



Enter the type of door opener. 1 = enable with ring, 2 = enable w/o ring = You can also open the door without a doorbell ring.

Deactivating the door opener:



Lift the handset.



Enter the code.



Dial the entrance telephone number.

Step by Step

Making Calls

Dialing Numbers



Lift the handset.



Internal calls: Enter the station number.
External calls: Enter the external code and the station number.

The called party does not answer or is busy:



Replace the handset.

Caller ID Suppression

You can prevent your station number or name from appearing on the displays of external parties you call. The feature remains active until you deactivate it.



Lift the handset.



Enter code for "suppress" or "restore".



The service personnel can turn caller ID suppression on and off for all telephones.

Talking to Your Colleague With a Speaker Call

You can make a loudspeaker announcement through a loudspeaker if connected (ask the service personnel), or to an internal user with an optiset E system telephone without any action on their part.



Lift the handset.



Enter the code.




Enter the station number.

Step by Step

Talking to Your Colleague with Discreet Calling (Not for HiPath 500)

If this function has been configured (ask your service personnel), you can join an ongoing call conducted by an internal user at a system telephone with display. You can listen in unnoticed and speak to the internal user without being overheard by the other party (discreet calling).



Lift the handset.

Enter the code.


Enter your internal station number.



Your service personnel can protect your telephone against discreet calling.

Activating Tone Dialing/DTMF Suffix-Dialing

You can transmit dual-tone multifrequency (DTMF) signals to control devices such as an answering machine or automatic information system.



You have set up a connection.

Enter the code.

You can use the keys "0" through "9", "*", and "#" to transmit DTMF signals.



Ending the call also deactivates DTMF suffix-dialing.

Your system may be configured so that you can start DTMF suffix-dialing immediately after setting up a connection.

Step by Step

Automatic Connection Setup (Hotline)

If this function is configured (contact the service personnel), the system automatically sets up a connection to a preset internal or external destination.



Lift the handset.

Depending on the setting, the connection is either set up **immediately** or only **after** a preset **period of time (hotline after a timeout)**.

Reserve Trunk

If this feature is configured (contact the service personnel), you can reserve a busy trunk for your own use. When the trunk is free, you receive a call.



Lift the handset.



Enter the external code. The external trunk is busy; you hear a busy signal tone. Wait about 5 seconds until the busy tone ends. The trunk is reserved.



Replace the handset.

When the reserved trunk becomes free:

Your telephone rings.



Lift the handset. You hear the CO dial tone.



Enter the number of the external station.

Step by Step

Assign Station Number

If this function has been configured (contact the service personnel), you can selectively assign a specific number (DID number) to your telephone before making an external call. The assigned number then appears on the called party's display.



Lift the handset.



Enter the code.



Enter the DID number you wish to use.



Dial the external number.

Associated Dialing/Dialing Aid

If this function has been configured (contact the service personnel), you can use your telephone as a dialing aid for other telephones.



Lift the handset.



Enter the code.



Enter the internal station number of the party for whom you want to dial.



Enter the number you wish to dial (external number with external code).

Step by Step

Calling Multiple Parties Simultaneously

Calling a Second Party (Consultation Hold; not for all ISDN Telephones)

You can call a second party while engaged in a call. The first party is placed on hold.



Press the key.

Call the second station.

Return to the first party:



Press the key.



Enter the code or wait two seconds.

or

(depending on the configuration)



Press the key twice.

Switching to the Party on Hold (Toggle; not for all ISDN Telephones)



Enter the code.

Combine the calling parties into a three-party conference



Enter the code.

Connecting the other parties to each other



Replace the handset.

Step by Step

Conducting a Conference (not for all ISDN Telephones)

In a conference call, you can talk to as many as four other parties at the same time. These may be internal or external users.



Lift the handset.



Call the first party.



Press the key.



Call the second station. Announce the conference.



Enter the code.

A tone sounds every 30 seconds to indicate that a conference is in progress. Contact the service personnel for instructions on how to turn it off.

If the second party does not answer:



Press the key.



Enter the code or wait two seconds.

or



Press the key twice.

Adding Up to Five Parties to the Conference (Initiator Only)



Press the key.



Call the new party. Announce the conference.



Enter the code.

etc.

Leaving a Conference



Replace the handset.

Ending a Conference (Initiator Only)



Enter the code.

Step by Step

Transferring a Call (not for all ISDN Telephones)

If the person you are speaking to wants to talk to another colleague of yours, you can transfer the call that colleague.



Press the key.

Enter the number of the party to which you want to transfer the call.



Announce the call, if necessary.



Replace the handset.

...After a Speaker Call (Announcement) in a Group

If this function has been configured (contact the service personnel), you can use a speaker call (announcement, → Page 14) to announce a call in progress to a group of users → Page 43.

After a member of the group has accepted the call request, you can transfer the waiting party.

Precondition: You are conducting a call.



Enter the code.



Enter the group's station number.



Announce the call.

When a member of the group accepts the call, you are connected to this party.



Replace the handset.



If the connection between the two other parties is not established within 45 seconds, the call from the first part returns to you (recall).

Step by Step

Parking a Call (not for all ISDN Telephones)

You can park up to ten calls, either internal, external, or both. Parked calls can be displayed on and picked up from another telephone. This feature is useful if you want to continue a call at another phone.

Precondition: You are conducting a call.



Enter the code.



Enter the number of the park slot (0 - 9) and make a note of it.

If the park slot number you entered is already being used, you will hear the negative confirmation tone. Please enter another number.



Replace the handset.

Retrieving a Parked Call

Precondition: One or more calls have been parked. The telephone is idle.



Lift the handset.



Enter the code.



Enter the park slot number you noted earlier.

If the park slot number you enter is not in use, you cannot retrieve the call.



If a parked call is not picked up, after a specific period of time the call is returned to the telephone from where it was parked (recall).

Picking up (Retrieving) a Held Call

Precondition: One or more calls have been parked. The telephone is idle.



Lift the handset.



Enter the code.



Enter the line number you noted earlier.

Step by Step

Making Calls to Stored Destinations

Using Station and System Speed-Dial Numbers

Precondition: You have stored station speed-dial numbers → Page 27 or the service personnel has stored system speed-dial numbers.



Lift the handset.



Enter the code.



Enter a speed-dial number.

"*0" to *9" = station speed-dialing.

"000" to "999" = system speed-dialing (contact the service personnel)..

If applicable

Suffix-dialing



If necessary, you can suffix-dial additional digits (for example, the user's extension) at the end of the saved station number.

If this feature is configured, a suffix is automatically dialed (for example, "0" for the exchange) if no entries are made within 4 or 5 seconds.

Step by Step

Checking and Assigning Call Charges

Dialing with Call Charge Assignment

You can assign external calls to certain projects.

Precondition: The service personnel has set up account codes for you.



Lift the handset.



Enter the code.



Enter the account code.

If necessary



Press this key (may be needed, depending on the configuration; contact the service personnel).



Enter the number of the external station.



You can also enter the account code during an external call.

Step by Step

If You Cannot Reach a Destination...

Call Waiting (Camp-On)

It is important that you reach the called party, but the number is busy.



Lift the handset.

Enter the internal station number.

Wait (approx. 5 seconds) until the busy tone is followed by the ring tone.

The called party can then respond → Page 9.



The called party can prevent automatic call waiting → Page 10.

If this feature is configured (contact the service personnel), you will hear the ring tone immediately.

Step by Step

Telephone Settings

Locking the Telephone to Prevent Unauthorized Use

You can prevent unauthorized persons from using your telephone during your absence.

Precondition: You must have configured a personal identification number (PIN) for your telephone → Page 26.

To lock and unlock the telephone:



Lift the handset.

7 5 6 6 or 7 6 6 6

Enter the code for "on" or "off".



Enter the telephone lock PIN → Page 26.



While the telephone is locked, a special dial tone sounds when you lift the handset. You can continue to dial internal numbers as usual.

An authorized party → Page 35 can also lock and unlock your telephone.

Step by Step

Saving Your PIN

To prevent unauthorized persons from using your telephone → Page 25 and to use another telephone like your own → Page 31, you need to enter a personal identification number, which you can save yourself.



Lift the handset.



Enter the code.



Enter the current five-digit PIN.

If you have not yet assigned a PIN, use the PIN "00000" the first time you enter it.



Enter the new PIN.



Repeat the new PIN.



If you forget your PIN, contact the service personnel, who can reset your PIN to "00000". An authorized party → Page 35 can also lock and unlock your telephone.

Step by Step

Saving Station Numbers and Appointments

Storing Station Speed-Dial Numbers

You can store the ten numbers which you use the most and dial them using your own station speed-dial numbers: *0 through *9 → Page 22.



Lift the handset.

Enter the code.



Enter the speed-dial number you wish to use (*0 to *9).



First enter the external code and then the external station number (wait approx. 5 seconds).

Saving Appointments

You can tell your telephone to give you a call when you want to be reminded of an appointment → Page 11.

To do this, you need to save the time you want the call to be made. The appointment can be set for any time within the next 24 hours.



Lift the handset.

Enter the code.



Enter a 4-digit time, such as 0905 for 9:05 (= 9.05 a.m.) or 1430 for 14.30 (= 2.30 p.m.).

Deleting a saved appointment



Lift the handset.

Enter the code.

Step by Step

Call Forwarding

Using Variable Call Forwarding

You can immediately forward internal or external calls to different internal or external telephones (destinations). (External destinations require special configuration in the system).

 Special features must be taken into consideration if your telephone operates with HiPath 5000 (system networking via PC network) → Page 45!



Lift the handset.

Enter the code.



Enter the line type you wish to use:

1 = all calls, 2 = external calls only, 3 = internal calls only



Enter the destination number (without the external code).



Lift the handset.

Enter the code.

 When call forwarding is active, a special dial tone sounds when you lift the handset.

If DID DTMF is active (contact the service personnel), you can also forward calls to this destination. Destinations: Fax = 870, DID = 871, Fax DID = 872.

Step by Step

Using Night Answer

When night answer mode is active, for example during a lunch break or after office hours, all external calls are immediately forwarded to a specific internal telephone (night station). The night station can be defined by the service personnel (standard night answer service) or by you (temporary night answer service).

 Special features must be taken into consideration if your telephone operates with HiPath 5000 (system networking via PC network) → Page 46!

Activating this function:



Lift the handset.



Enter the code.



Enter the destination number (= temporary night answer service) within 5 seconds.

or



Enter the code or use the default (= standard night answer service).

Deactivating this function:



Enter the code.

Step by Step

Using Other Functions

Sending a Message

On system telephones with no display (e.g. optiPoint 500 entry), on ISDN, pulse or tone dialling telephones, transmitted text messages will be saved as a callback request.



Lift the handset.



Enter the code.



Enter the internal station number of the recipient or group.



Select the preprogrammed message (which can be changed by the service personnel). Enter the code.

- | | |
|------------------------|------------------------|
| 0 = Please callback | 5 = Fax waiting |
| 1 = Someone is waiting | 6 = Dictation please |
| 2 = Appointment | 7 = Please come see me |
| 3 = Urgent call | 8 = Please make copies |
| 4 = Do not disturb | 9 = Ready to depart |

Deleting Sent Messages



Lift the handset.



Enter the code.



Texts sent to groups can be deleted only by the originator.

Answering Messages

If there is a message for you, you will hear a special dialling tone or an announcement when you lift the handset.



Lift the handset.



Enter the code.

This connects you to the sender of the message or the mailbox system.

Step by Step

Using Another Telephone Like Your Own

Other people can temporarily use your telephone for outgoing calls as though it were their own.



Lift the handset.



Enter the code.



Enter the other user's station number.



Enter the other user's telephone lock PIN.



Dial the external number.

This state is canceled at the end of the call.

Resetting Services and Functions (System-Wide Cancellation for a Telephone)

There is a general reset procedure for activated functions. The following functions are canceled, if they were activated:

- Forwarding on
- Advisory msg. on
- Ringing group on
- Hunting group off
- Suppress call ID
- Waiting tone off
- DND on
- Ringer cutoff on
- Messages received:
- View callbacks



Lift the handset.



Enter the code.

Step by Step

7 5 4 9 3

if applicable



Recording Calls

If configured (contact the service personnel), you can record calls.

Precondition: You are conducting a call.

Enter the code.

An announcement notifies you and the person you are speaking with that recording has begun. A beep will also sound every 15 seconds until recording has concluded.



While a call is being recorded, a third party cannot be added to the call.

Ending Recording

Replace the handset.

You receive a recall. Lift the receiver to continue the call without activating call recording.

Playback

The steps required for playing back a recording depend on the voice memory system (see the corresponding Operating Manual or → Page 11).

Step by Step

Monitoring a Room

A telephone can be used to monitor a room. The function must be activated on the telephone that you want to monitor.

Calling this telephone lets you hear what is going on in the room.

Activating the telephone to be monitored:



Lift the handset and direct it towards the noise source.

Enter the code.

Deactivating the telephone to be monitored:



Replace the handset.

Monitoring the room:



Lift the handset.

Enter the internal number if the telephone in the room you wish to monitor.

Step by Step

Activating Functions for Another Telephone

If this function has been configured (contact the service personnel), you can turn the following functions on and off for other telephones. This feature is also known as associated service.

- Do not disturb, code 75 97/76 97 → Page 11
- Call forwarding, code 75 11, 75 12, 75 13/76 1 → Page 28
- Lock and unlock all phones, code 75 66/76 66 → Page 25
- Group ringing, code 75 81/76 81 → Page 43
- Group call, code 76 85/75 85 → Page 42
- Reset services and functions, code 76 0 → Page 31
- Control relay, code 75 80/76 90 → Page 38
- Night service, code 75 44/76 44 → Page 29
- Timed reminders, code *65 → Page 27



Lift the handset.



Enter the code.



Enter the internal number of the telephone for which you want to activate the function.



Enter the code – e.g. 76 97 for DND on – and procedure (if relevant).

Step by Step

Locking Another Telephone to Prevent Unauthorized Use

If this function has been configured (contact the service personnel), you can lock other telephones to prevent unauthorized use, and later unlock them again.

You can use this function to unlock the telephone for users who have locked their telephones and then forgotten their PINs.



Lift the handset.



Enter the code.



Enter the internal number of the telephones that you want to lock or unlock.



or



Enter the code for "Changeover on".

Enter the code for "Changeover off".

Using System Functions from the Outside (DISA: Direct Inward System Access)

If this function has been configured (contact the service personnel), you can set up external outgoing calls from outside the system, just like an internal user. You can also activate and deactivate the following functions in your system:

- Reset services and functions, code #0 → Page 31
- Call forwarding, code: *1/#1 → Page 28
- Lock and unlock all phones, code: *66/#66 → Page 25
- Save PIN, code: *93 → Page 26
- Send a message, code: *68/#68 → Page 30
- Group ringing, code: *81/#81 → Page 43
- Group call, code: *85/#85 → Page 42
- Suppress caller ID, code: *86/#86 → Page 14
- Open door, code: *61 → Page 12
- Door opener on/off, code: *89/#89 → Page 13
- Control relay, code *90/#90 → Page 38

Step by Step

- Do not disturb, code: *97/#97 → Page 11
- Speed-dialing, code: *7 → Page 22
- Associated service, code: *83 → Page 34

Precondition: You have a telephone that uses tone dialing (DTMF dialing) or you can switch your telephone to tone dialing. The telephone is not connected to the system.



Set up a call to the system. Enter the station number (contact the service personnel).



Wait for a continuous tone (if necessary switch the telephone to tone dialing), then enter the internal number that has been assigned to you and the associated PIN.



Enter the code (necessary only if programmed in the system).



Wait for a dial tone and then enter the code, e.g. *97 for "Do not Disturb On". Make other inputs as necessary (refer to the operating instructions for pulse and DTMF telephones).

or



Dial the external number.



You can only execute one function at a time, or set up only one outgoing connection.

The connection is immediately released after successful activation of a function.

In the case of an external-external call, the connection is released as soon as either of the parties ends the call.

Step by Step

Controlling Connected Computers or Other Programs and Telephone Data Service (Not for HiPath 500)

If this function has been configured (contact the service personnel), you can control connected computers or programs running on them, such as hotel services or information systems, from your telephone.

Precondition: You have set up a connection.

R 7 5 4 2

Enter the code.

The connected computer now prompts you to enter the data, which you can do in one of two ways. Contact the service personnel to find out which option is programmed in your system:

- Input in en-bloc mode

0 ... 9

Enter data.

7 6

Press this key at the end of the entry.

or

- Input in online mode:
The connected computer processes your entries directly.

7 6

Enter the code.

0 ... 9

Enter data.

Step by Step

Controlling Relays (Not for HiPath 500/HiPath 2000)

If this feature is configured (contact the service personnel), you can turn up to four relays on and off to control different facilities (such as a door opener). Depending on how they are programmed, you can switch the relays on and off or switch them on and have them switched off automatically after a timeout.

 Special features must be taken into consideration if your telephone operates with HiPath 5000 (system networking via PC network) → Page 47!



Lift the handset.

Enter the code for "on" or "off".

Enter the relay.

Step by Step

Paging (Not for HiPath 500)

If paging equipment is connected to your system (contact the service personnel), you can contact people via their pocket receivers.

The pocket receiver indicates to the person you are looking for that someone is trying to get in touch. The person you page can then go to the nearest telephone and call you.

Paging:

To be paged, you must have activated a call ringing group → Page 43, call forwarding → Page 28, or call redirection to the internal station number of your paging equipment.

A call request is then signaled automatically.

Answering the page from the nearest telephone:



Lift the handset.



Enter the code.



Enter your own station number.

Step by Step

Team and Executive/Secretary Functions With Assigned Trunk Lines

If this function has been configured (contact the service personnel), you belong to a team of users for whom special trunk lines exist. You can then conduct your calls as usual via the trunk assigned to you. In addition, you can also activate call forwarding or a ring transfer for the lines of your group.

Forwarding Calls on Lines

You can immediately forward internal or external calls on lines of your group to different internal or external telephones (destinations); even external destinations are possible in certain system configurations. Activating call forwarding for one line activates the function for all members in your group.



Lift the handset.



Enter the code.



Enter the number of the trunk key you wish to use.



Enter the line type you wish to use:

1 = all calls, 2 = external calls only, 3 = internal calls only



Enter the destination number (without the external code).



Lift the handset.



Enter the code.



Enter the number of the trunk key you wish to use.



If you have activated call forwarding for a trunk, a special dial tone sounds when the line is seized.

Step by Step

Transferring Calls Directly to the Executive (Only in an Executive/Secretary Group)

Normally, audible signaling of all calls for the executive is heard only in the secretary's office.

You can activate audible signaling so that calls are only signaled on the executive telephone and on a second telephone assigned to it.

Activating this function:



Lift the handset.

7 5 5 0 2

Enter the code.



Enter the number of the trunk key you wish to use.

Deactivating this function:



Lift the handset.

7 6 5 0 2

Enter the code.



Enter the number of the trunk key you wish to use.

Step by Step

Using Other Team Functions

Turning Group Call On and Off

If this function has been configured (contact the service personnel), you belong to one or more groups of users who can each be reached under a hunt group or group call number.

Incoming calls are signaled on all group member telephones in the order in which they are received (hunt group) or simultaneously (= group call) until one member of the group accepts the call.

You can also belong to a team (including executive/secretary ones) to which multiple lines have been assigned. → Page 40.

Each member of the group remains available under his or her own station number.

You can activate and deactivate the audible signal for a hunt group, group call or individual trunks in a group (including an executive/secretary team).

 Special features must be taken into consideration if your telephone operates with HiPath 5000 (system networking via PC network) → Page 44!

You belong to a hunt group or a group call:



Lift the handset.

 7 6 8 5 or  7 5 8 5 

Enter the code for "leave" or "join".

You belong to multiple groups or to one group with lines (including executive/secretary teams):



Lift the handset.

 7 6 8 5 or  7 5 8 5

Enter the code for "leave" or "join".

 7 6 

Enter the code for "Leave all groups".

or

 7 5 

Enter the code for "Join all groups".



Enter a group/trunk number to directly "leave or join".

Step by Step



If you deactivate the audible tone for another group or trunk, or deactivate it for all groups and trunks to which you belong, a special dial tone sounds when you lift the handset.

Accepting a Call for Another Member of Your Team

You can accept calls for other telephones in your team from your telephone even while engaged in another call. To do this, contact the service personnel to find out if a pickup group has been configured.

Precondition: Your telephone rings briefly.

Lift the handset.

Enter the code.


7 5 5 7

Activating and Deactivating a Ringing Group

You can have calls for your telephone signaled audibly at up to five other phones. The person who answers first receives the call.



Special features must be taken into consideration if your telephone operates with HiPath 5000 (system networking via PC network) → Page 47!

Saving telephones for the ringing group:

Lift the handset.

Enter the code.

Enter the internal station number.


7 5 8 1



Removing all telephones in call ringing group:

Lift the handset.

Enter the code.


7 6 8 1 

Step by Step

Special Functions in the LAN (Not for HiPath 500)

If your telephone is operating in a HiPath 5000 environment, multiple HiPath 2000/HiPath 3000 systems are interconnected via a LAN (**L**ocal **A**rea **N**etwork, e.g. proprietary PC network). Your telephone calls are conducted via the LAN (PC network).

If this is the case, you must take certain special features into consideration when performing various functions. These are described below.

Leaving a Hunt Group/Group Call

Precondition: you belong to the hunt group/group call
→ Page 42 of another HiPath 2000/HiPath 3000:



Lift the handset.



Enter the code.



Enter the (DISA) call number of the other HiPath 2000/HiPath 3000.



Enter.



Enter the (DISA) call number of your telephone.



Enter.



Enter the code for "leave" or "join".

**You belong to multiple groups of another
HiPath 2000/HiPath 3000:**



Enter the group number for "Join/Leave, directed".

Step by Step

Transferring Call Forwarding

You can activate/deactivate call forwarding → Page 28 for your telephone from other HiPath 5000 telephones.



Lift the handset.

7 5 4 7

Enter the code.



Enter the (DISA) call number of the HiPath 2000/ HiPath 3000 to which your telephone is connected.

7 6

Enter.



Enter the (DISA) call number of your telephone.

7 6

Enter.

Activating this function:

7 5 1

Enter the code.

1 or 2 or 3

Enter the line type you wish to use:

1 = all calls, 2 = external calls only, 3 = internal calls only



Enter the destination number (without external code).

Deactivating this function:

7 6 1

Enter the code.

Step by Step

Using Night Answer

If authorized (contact the service personnel), you can also define telephones in other HiPath 2000/HiPath 3000 communications platforms as the night answer → Page 29.



Lift the handset.



Enter the code.



Enter the (DISA) call number of the HiPath 2000/HiPath 3000 to which the night answer telephone is connected.



Enter.



Enter the (DISA) call number of the telephone from which you wish to activate/deactivate the night answer service.



Enter.

Activating this function:



Enter the code.



Enter the destination number (= temporary night answer service) within 5 seconds.

Deactivating this function:



Enter the code.

Step by Step

Activating and Deactivating a Ringing Group

You can have calls for your telephone signaled audibly at external telephones or at telephones in other HiPath 2000/HiPath 3000 communications platforms → Page 43.

Saving the telephones for the ringing group:



Lift the handset.



Enter the code.



Enter the call number.



Enter.

Removing all telephones in call ringing group:



Lift the handset.



Enter the code.

Step by Step

Controlling Relays (Not for HiPath 2000)

If this feature is configured (contact the service personnel), you can also control relays → Page 38 in other HiPath 3000 communications platforms.



Lift the handset.



Enter the code.



Enter the (DISA) call number of the HiPath 3000 in which the relay is to be controlled.



Enter.



Enter the (DISA) call number of the telephone from which you wish to control the relay.



Enter.



Enter the code for "on" or "off".



Enter the relay.

Step by Step

Opening the Door

If this feature is configured (contact the service personnel), you can also activate the door opener → Page 12 in other HiPath 2000/HiPath 3000 communications platforms.



Lift the handset.



Enter the code.



Enter the (DISA) call number of the HiPath 2000/HiPath 3000 in which the door is to be opened.



Enter.



Enter the (DISA) call number of the telephone from which you wish to activate the door opener.



Enter.



Enter the code.



Enter the call number of the entrance telephone.

Documentation

You can find these operating instructions in the Internet in PDF format under <http://www.siemens.com/hipath>

and on CD-ROM (ask the service personnel) in HTML and PDF format.

In order to look at and print the operating instructions in PDF format, you need a computer on which the free Acrobat Reader software package is installed by Adobe.

To look at the operating instructions in HTML format you need a computer with a www browser, e.g. Microsoft Internet Explorer.

Index

A

account code	23
announcement	14
answering a timed reminder	11
appointment	27
assigning a DID number	17
associated dialing/dialing aid	17
associated service	34
automatic connection setup	16

C

call	
accepting, group	43
answering	8
entrance telephone	12
forwarding	28
forwarding in a team	40
parking	21
pickup, directed	10
retrieving from park	21
retrieving held	21
transfer after announcement	20
call charge assignment	23
call forwarding	28
call recording	32
call signal	8
call transfer	20
call waiting	
accepting	9
allowing	10
preventing	10
call waiting (camp-on)	24
tone off	10
call waiting on/off	10
call waiting tone on/off	10
caller ID	
restoring display of	
suppressing display of caller ID	14
caller ID suppression	14
calling a second party	18
conference	18
connection setup, automatic	16
consultation hold	18

D

dialing	
internal/external calls	14
dialing internal calls	14
dialing numbers	
using speed-dialing	22
direct inward system access (DISA)	35
DISA	35
discreet calling	15
do not disturb	11
door opener	13
DTMF suffix-dialing (tone dialing)	15

E

entrance telephone	12
executive/secretary functions	40
explanation of symbols	6
external code	14

F

forwarding	28
functions	
activating/deactivating	
for another telephone	34
resetting	31

G

group call	42
------------------	----

H

HiPath 5000	
actuators	48
group call	44
hunt group	44
night answer	46
opening the door	49
relays	48
ringing group	47
transferring call forwarding	45
hotline	16
hunt group	42

I
IP telephony 44

L
LAN telephony 44
locking
 all phones 35
locking all phones 35
locking/unlocking the telephone 25

M
mailbox 11
making calls
 to stored destinations 22
 with the dialing aid 17
making external calls 14
making trunk calls 14
message
 answering 30
 deleting/displaying 30
 receiving 30
 sending 30

N
night answer 29

O
open door
 with a code 13
operating principle 7
operating steps 6

P
parking a call 21
personal identification number 26
pickup (call) 10, 43
PIN 26
 for a telephone 25
preventing and allowing
 automatic camp-on 10
programming your telephone 25
project calls 23

R
radio paging equipment PSE 39
recall 20
recording 32
relays 38
reserving a trunk 16
resetting functions 31
resetting services 31
ring transfer
 in an executive/secretary team 41
ringing group 43
room monitor 33

S
saving a PIN 26
secretary functions 40
setting your telephone 25
speaker call 14
special dial tone 11
speed-dialing
 dialing numbers 22
 saving station speed-dialing 27
 suffix-dialing 22
 system 22
station number
 assigning 17
station speed-dialing 22, 27
suffix-dialing 15
 automatic 22
 DTMF tone dialing 15
switches 38
system speed-dialing 22
system-wide cancellation 31

T
team with trunk keys 40
telephone
 locking 25
 locking another 35
 locking/unlocking 25
 locking/unlocking all phones 35
 operating 7
 settings 25
 using another like your own 31
telephone data service 37

temporary phone
 using a temporary phone 31

text message
 answering 30
 deleting/displaying 30
 receiving 30
 sending 30

three-party conference 18

time-dependent hotline 16

toggle 18

tone dialing 15

tone dialing (DTMF dialing) 15

trace call 12

transfer (call)
 after announcement 20

transfer call 20

trunk keys in a team 40

trunk, reserving 16

U

using functions from the outside 35

V

variable call forwarding 28

Overview of Functions/Codes (Alphabetical)

The table below lists all available functions. If these functions have been configured (contact the service personnel), they can be called by entering a code.

Functions		Operating Steps
Accept call	Directed	7 5 5 9 Int.
	Group	7 5 5 7
Answer call		
Assign station number (not for U.S.)		7 5 4 1 MSN Ext.
Associated dialing		7 5 6 7 Int. Stn No.
Associated service		7 5 8 3 Int.
Call charge assignment/account code		7 5 6 0 ACCT 7 6 if appl. Ext.
Call forwarding	On	7 5 1 1 Ext.
		7 5 1 2 Ext.
		7 5 1 3 Ext.
Off		7 6 1
Forward Line: On		7 5 5 0 1 Trk No 1 Ext.
		7 5 5 0 1 Trk No 2 Ext.
		7 5 5 0 1 Trk No 3 Ext.
Forward Line: Off		7 6 5 0 1 Trk No
Call recording		R 7 5 4 9 3
Call waiting (camp-on)		Int. Stn busy; wait 5 seconds

Functions		Operating Steps
Camp-on	Accept a waiting call (camp-on)	  or R 7 5 5 5
	Terminate second call, resume first call	R 7 5 0 / Wait 2 sec. / R 2x
	Prevent call waiting (automatic camp-on)	 7 6 4 9 0 
	Allow call waiting (automatic camp-on)	 7 5 4 9 0 
	Call waiting tone on	 7 6 8 7 
	Call waiting tone off	 7 5 8 7 
Conference	Start	  Stn. No. R  Stn. No. R 7 5 3
	The other party does not respond 1. Continue the call	R 7 5 0 / Wait 2 sec. / R 2x
	Add a party to the conference (max. five)	R  Stn No. R 7 5 3 etc.
	Leave conference	
	Remove party	R 7 6 3
Consult		 R  Stn. No.
	Quit consultation, resume first call	R 7 5 0 / Wait 2 sec. / R 2x
	Toggle	R 7 5 2
	Start three-party conference	R 7 5 3
	Connect parties	
Control relay (not for HiPath 500/ HiPath 2000)	On	 7 5 9 0 1...4 
	Off	 7 6 9 0 1...4 
Discreet Calling (Not for HiPath 500)		 7 5 9 4 5  Int.

Overview of Functions/Codes (Alphabetical)

Functions		Operating Steps
DND	On	7 5 9 7
	Off	7 6 9 7
Door opener	Conversation (entrance telephone)	/ after 30 seconds Int.
	Open door	R 7 5 6 1 Int.
	Door release on	7 5 8 9 Int. + Code 1 or 2
	Door release off	7 6 8 9 Int.
DTMF dialing / Tone dialing (only pulse telephone)		7 5 5 3
Ending a call		
Group call	Leave	7 6 8 5 or 7 6 8 5 7 6 or 7 6 8 5 Group
	Join	7 5 8 5 or 7 5 8 5 7 5 or 7 5 8 5 Group
Hotline		
Making calls		Stn No.
Message	Send	7 5 6 8 Int. 0 ... 9
	Delete (sent)	7 6 6 8 1
	Answering	7 6 6 8 3
Night answer	On	7 5 4 4 Intern or 7 5 4 4 7 5
	Off	7 6 4 4
Paging another person (not for U.S., not for HiPath 500)	Answer page	* 5 9 Int.

Functions		Operating Steps
Park a call		R 7 5 5 6 0...9
	Retrieve parked call	7 6 5 6 0...9
Phone	Changeover on (lock/unlock)	7 5 6 6 Code
	Changeover off (lock/unlock)	7 6 6 6 Code
	Lock all phones	7 5 9 4 3 Int. 7 5
	Unlock all phones	7 5 9 4 3 Int. 7 6
Picking up (retrieving) a held call	7 5 6 3 Line No.	
Reset services	7 6 0	
Ring transfer	On	7 5 5 0 2 Line No.
	Off	7 6 5 0 2 Line No.
Ringing group	On	7 5 8 1 Int.
	Off	7 6 8 1
Room monitor	On	7 5 8 8
	Off	
	Monitoring a room	Int.
Saving a PIN		7 5 9 3 Old code 2X new code
Speaker call		7 5 8 0 Int.
Speed-dialing	Use speed-dialing	7 5 7 *0...*9 or 000...999
	Speed-dialing: store station	7 5 9 2 *0... *9 Ext.
Suppress caller ID	On	7 5 8 6
	Off	7 6 8 6
Telephone data service (not for HiPath 500)		R 7 5 4 2 0...9 7 6 or R 7 5 4 2 7 6 0...9

Overview of Functions/Codes (Alphabetical)

Functions		Operating Steps
Timed reminder	Save	7 5 4 6 (Time, e.g. 0905)
	Delete	7 6 4 6
	Accept timed call	
Trace call (not for U.S.)		R 7 5 8 4
Transferring a call		R Stn No., announce if appl.
	...After announcement to group	R 7 5 8 0 Group
Trunk	Reserve trunk	Busy (external) Wait 5 seconds
	When the reserved trunk is free	Ext.
Using another phone temporarily		7 5 5 0 8 Int. Code
Using mailboxes		7 6 6 8 3

www.siemens.com/hipath



The information provided in this document contains merely general descriptions or characteristics of performance which in case of actual use do not always apply as described or which may change as a result of further development of the products.

An obligation to provide the respective characteristics shall only exist if expressly agreed in the terms of contract.

The trademarks used are owned by Siemens AG or their respective owners.

© Siemens AG 2006
Siemens Communications
Hofmannstr. 51 • D-81359 München

Ref. No.: A31003-H1012-C101-12-7619

Subject to availability. Right of modification reserved.
14.08.06